## **Rack Mount Kit**

Model: X-WS-RMK

## Installation Instructions

- Insert rack mount ears into sides of WebSwitch™. Note that rack mount ears can be oriented so that WebSwitch™ faces either direction.
- Using the two white securing pins, insert the pins on the underside of WebSwitch™, press firmly until the securing pins are flush.
- Place WebSwitch™ in the desired location in the rack. Note in some installations, rubber bumpers on underside of WebSwitch™ may need to be removed.
- Secure WebSwitch™ to the rack using the four screws provided. Note: some racks may require different screws than those provided.

To remove the rack mount kit from WebSwitch™, remove the white securing pins from the underside of WebSwitch™. Do not discard these pins, they are reusable.



